

treatment method. If infestations of wood-destroying pests extend or exist beyond the area(s) of local treatment, they may not be exterminated.”)

When a complete inspection is performed, a recommendation shall be made to remove or cover all accessible pellets and frass of wood-destroying pests.

When a limited inspection is performed, the inspection report shall state that the inspection is limited to the area(s) described and diagrammed. A recommendation shall be made to remove or cover all accessible pellets and frass of wood-destroying pests in the limited areas. The limited inspection report shall include a recommendation for further inspection of the entire structure and that all accessible evidence of wood-destroying pests be removed or covered.

(9) For the extermination of subterranean termite infestations, treat an infested area under the structure when subterranean termite tubes are found connected to the ground or when active infestations are found in the ground. Subterranean termite tubes shall be removed where accessible, except where a licensee is using an above ground termite bait station that requires the use of the termite tubes to be effective. Where a licensee is using an above ground termite bait station that requires the use of termite tubes to be effective, subterranean termite tubes can remain in place for the duration of the licensee’s use of the termite bait stations. At the conclusion of the treatment, the subterranean termite tubes shall be removed.

(10) Comply with the provisions of section 2516(c)(2) of Title 24 of the California Code of Regulations.

(11) Correct any excessive moisture condition that is commonly controllable. When there is reasonable evidence to believe a fungus infection exists in a concealed wall or area, recommendations shall be made to open the wall or area.

(12) Repair a stall shower if it is found to leak when water tested for a minimum of fifteen (15) minutes after the shower drain has been plugged and the base filled to within one (1) inch of the top of the shower dam. Stall showers with no dam or less than two (2) inches to the top of the dam are to be water tested by running water on the unplugged shower base for a minimum of five (5) minutes. Showers over finished ceilings must be inspected but need not be water tested. If water stains are evident on the ceiling, recommendations shall be made for further inspection and testing.

(b) Preconstruction application of termiticide for protection from subterranean termites shall not be made at less than the manufacturer's label specifications.

(c) If in the opinion of the inspector a building permit is required, it must be noted on the wood destroying pests and organisms inspection report (Form No. 43M-41 as specified in section 1996 of the California Code of Regulations).

NOTE: Authority cited: Section 8525, Business and Professions Code. Reference: Section 8516, Business and Professions Code.

#### HISTORY

1. Amendment filed 9-16-59; effective thirtieth day thereafter (Register 59, No. 16).
2. Amendment filed 5-19-64; designated effective 9-1-64 (Register 64, No. 11).